2010 Honda CR-V






Remote Start, Security, Ke	eyless Entry, Accessories		
ltem	Wire Color	Polarity	Wire Location
12 Volts	white (50A)	+	ignition switch, brown 7 pin plug, pin 3
Second 12 Volts	N/A		
Starter	yellow	+	ignition switch, brown 7 pin plug, pin 1
Second Starter	N/A		
gnition	blue	+	ignition switch, brown 7 pin plug, pin 6
econd Ignition	N/A		
Third Ignition	N/A		
Accessory	orange	+	ignition switch, brown 7 pin plug, pin 4
Second Accessory	red	+	ignition switch, brown 7 pin plug, pin 5
Third Accessory	N/A		
Keysense	gray	-	ignition key switch, green 6 pin plug, pin 1
Data Bus	green (S-NET immobilizer data)	data	Immobilizer Control Unit, white 7 pin plug, pin 3
Can Bus High	N/A		
an Bus Low	N/A		
Can Bus Sw	pink (B-CAN)	data	Immobilizer Control Unit, white 7 pin plug, pin 4
Power Lock	blue	-	driver kick, door harness
Power Unlock	gray	-	driver kick, door harness
ock Motor	pink	5 wire	dash fuse box, green 42 pin plug (E), pin 21
Driver Unlock Motor	gray	5 wire	driver kick, door harness
Passenger Unlock Motor	yellow	5 wire	dash fuse box, green 42 pin plug (E), pin 14
Parking Lights (-)	blue	-	headlight switch, white/black 12 pin plug, pin 11
Parking Lights (+)	red	+	above driver kick, blue 18 pin plug, pin 1
lazards	purple	+	hazard switch, green 6 pin plug, pin 5
īurn Signal (Left)	orange	+	dash fuse box, green 42 pin plug (E), pin 40
īurn Signal (Right)	brown	+	dash fuse box, green 42 pin plug (E), pin 39
leadlight	pink	-	headlight switch, white/black 12 pin plug, pin 10
AutoLights	orange (ground to turn off autolights)	-	headlight switch, white/black 12 pin plug, pin 9
Reverse Light	brown	+	dash fuse box, green 42 pin plug (E), pin 15
eft Front Door Trigger	green	-	dash fuse box, green 42 pin plug (E), pin 37
Right Front Door Trigger	lt. green	-	dash fuse box, green 42 pin plug (E), pin 3
eft Rear Door Trigger	white	-	dash fuse box, green 42 pin plug (E), pin 17
Right Rear Door Trigger	gray	_	dash fuse box, green 42 pin plug (E), pin 2

Remote Start, Security, Keyle	ess Entry, Accessories (Continue	ed)	
ltem	Wire Color	Polarity	Wire Location
Dome Supervision	purple	-	right of dash fuse box, white 20 pin plug, pin 19
Trunk/Hatch Pin	pink	-	dash fuse box, green 42 pin plug (E), pin 36
Rear Glass Pin	N/A		
Hood Pin	lt. blue	-	dash fuse box, blue 21 pin plug (G), pin 13
Trunk/Hatch Release	white (rear handle switch)	-	dash fuse box, green 42 pin plug (E), pin 13
Trunk Release Motor	green	+	dash fuse box, green 42 pin plug (E), pin 20
Fuel Door Release	N/A		
Power Sliding Door (Left)	N/A		
Power Sliding Door (Right)	N/A		
Factory Alarm Arm	pink (driver door key cylinder)	-	driver kick, door harness
Factory Alarm Disarm	brown (driver door key cylinder)	-	driver kick, door harness
Disarm No Unlock	see factory alarm disarm		
Trunk Alarm Shunt	N/A		
Tachometer	NOT yellow/black	ас	any fuel injector
Wait to Start	N/A		
Neutral Safety	N/A		
Clutch Pedal	N/A		
Fuel Pump	green	+	dash fuse box, green 42 pin plug (E), pin 9
Rear Defroster	lt. green	- latched	below dash fuse box, white 24 pin plug, pin 11
Mirror Defroster	same as rear defroster		
Left Front Heated Seat	blue (L), lt. blue (H)	+ latched	driver seat heater switch, white 6 pin plug, pins 3 and 6
Right Front Heated Seat	red (L), yellow (H)	+ latched	passenger seat heater switch, white 7 pin plug, pins 4 and 7
Speed Sense	blue	ac	radio, gray 17 pin plug, pin 13 or gray 24 pin plug, pin 15
Brake Wire	lt. green	+	dash fuse box, green 42 pin plug (E), pin 34
Parking Brake	purple	-	below dash fuse box, white 24 pin plug, pin 10
Horn Trigger	orange	-	horn switch, white 20 pin plug, pin 1
Wipers	orange (low), white (high), black (ground)	-	wiper switch, white/black 8 pin plug, pins 2, 4, and 5
Left Front Window (Up/Down)	pink - gray	A	power window master switch, gray 22 pin plug, pins 10 and 9
Right Front Window (Up/Down)	orange - brown	A	driver kick, door harness
Left Rear Window (Up/Down)	green - purple	А	above driver kick, blue 18 pin plug, pins 10 and 15
Right Rear Window (Up/Down)	lt. blue - red	A	driver kick, door harness
Sun Roof (Open/Close)	lt. blue and purple (open) (with ignition on only)	-	moonroof switch, gray 12 pin plug, pins 6 and 10
Sun Roof (Limit/Close)	orange and purple (close) (with ignition on only)	-	moonroof switch, gray 12 pin plug, pins 8 and 10
Memory Seat 1	N/A		
Memory Seat 2	N/A		
Memory Seat 3	N/A		

Audio			
ltem	Wire Color	Polarity	Wire Location
Radio 12V	orange or lt. green	+	radio, gray 17 pin plug, pin 17 or gray 24 pin plug, pin 24
Radio Ground	black	-	radio, gray 17 pin plug, pin 9 or gray 24 pin plug, pin 12
Radio Ignition	white	+	radio, gray 17 pin plug, pin 14 or gray 24 pin plug, pin 14
Radio Illumination	gray (parking lights), red (dimmer)	+,-	radio, gray 17 pin plug, pins 10, 1 or gray 24 pin plug, pins 13, 1
Factory Amp Turn-on	red	+	radio, gray 20 pin plug, pin 16 or gray 24 pin plug, pin 17
Power Antenna	black	+	radio, gray 3 pin plug, pin 3
Left Front Speaker (+/-)	lt. green - green or red - green	+,-	radio, gray 17 pin plug, pins 12, 3 or gray 24 pin plug, pins 23, 22
Right Front Speaker (+/-)	white - yellow or brown - yellow	+,-	radio, gray 17 pin plug, pins 15, 7 or gray 24 pin plug, pins 19, 18
Left Rear Speaker (+/-)	gray - brown or lt. green - purple	+,-	radio, gray 17 pin plug, pins 11, 2 or gray 24 pin plug, pins 11, 10
Right Rear Speaker (+/-)	blue - orange or blue - pink	+,-	radio, gray 17 pin plug, pins 16, 8 or gray 24 pin plug, pins 7, 6
Center Channel (+/-)	N/A		
Subwoofer (+/-)	pink - blue	+,-	radio, 5 pin plug, pins 4 and 5
Aux. Audio Input Left (+/-)	white - red (LX), white - black (EX)	+,-	radio, gray 20 pin plug, pins 13 and 3
Aux. Audio Input Right (+/-)	black - red (LX), red - black (EX)	+,-	radio, gray 20 pin plug, pins 14 and 3
RSE Video (+/-)	N/A		
RSE Audio Left (+/-)	green - black (USB, CD changer, and XM audio)	+,-	radio, white 14 pin plug, pins 6 and 14
RSE Audio Right (+/-)	red - white (USB, CD changer, and XM audio)	+,-	radio, white 14 pin plug, pins 5 and 13
Satellite Radio 12 Volts	orange	+	XM Receiver, white 14 pin plug, pin 1
Satellite Radio Ground	lt. blue	-	XM Receiver, white 14 pin plug, pin 11
Satellite Radio Ignition	purple	+	XM Receiver, white 14 pin plug, pin 2
Satellite Radio Antenna	(coaxial cable)		
Satellite Audio Left (+/-)	green - black	+,-	XM Receiver, white 14 pin plug, pins 6 and 14
Satellite Audio Right (+/-)	red - white	+,-	XM Receiver, white 14 pin plug, pins 5 and 13


What Fits			
ltem	Size	Depth	Location
Headunit	irregular		center of dash
Left Front Speaker	6.5		left front door
Left Front Tweeter			left front dash
Right Front Speaker	6.5		right front door
Right Front Tweeter			right front dash
Left Rear Speaker	6.5		left rear door
Left Rear Tweeter	N/A		
Right Rear Speaker	6.5		right rear door
Right Rear Tweeter	N/A		
Center Channel	N/A		
Subwoofer			under passenger seat
Left Front Headrest			
Right Front Headrest			
Left Rear Headrest			
Right Rear Headrest			
Satellite Radio Tuner			passenger kick

Wiring Photo and Notes: 12 Volts




Wiring Photo and Notes: Starter

	Notes:
	There are currently no notes for this item.




Wiring Photo and Notes: Ignition




Wiring Photo and Notes: Accessory

Notes:
There are currently no notes for this item.




Wiring Photo and Notes: Second Accessory




Wiring Photo and Notes: Data Bus

Notes:
The Immobilizer Control Unit is around the ignition key switch. The immobilizer ignition is lt. blue in pin 2, and ground is brown in pin 7.




Wiring Photo and Notes: Can Bus Sw



Wiring Photo and Notes: Power Lock

Notes:
There are currently no notes for this item.




Wiring Photo and Notes: Power Unlock




Wiring Photo and Notes: Lock Motor

Notes:
There are currently no notes for this item.




Wiring Photo and Notes: Driver Unlock Motor




Wiring Photo and Notes: Passenger Unlock Motor

Notes:
There are currently no notes for this item.
· · · · · · · · · · · · · · · · · · ·




Wiring Photo and Notes: Parking Lights (-)




Wiring Photo and Notes: Turn Signal (Left)

Notes:
There are currently no notes for this item.




Wiring Photo and Notes: Turn Signal (Right)




Wiring Photo and Notes: Headlight

Notes:
There are currently no notes for this item.




Wiring Photo and Notes: AutoLights




Wiring Photo and Notes: Reverse Light

Notes:
There are currently no notes for this item.




Wiring Photo and Notes: Left Front Door Trigger




Wiring Photo and Notes: Right Front Door Trigger

Notes: are currently no notes for this item.	
are currently no notes for this item.	Notes:
	e are currently no notes for this item
	e are currently no notes for this item.




Wiring Photo and Notes: Left Rear Door Trigger




Wiring Photo and Notes: Right Rear Door Trigger

Notes:
ere are currently no notes for this item.
-




Wiring Photo and Notes: Dome Supervision




Wiring Photo and Notes: Trunk/Hatch Pin

Notes:
There are currently no notes for this item.




Wiring Photo and Notes: Trunk/Hatch Release



Wiring Photo and Notes: Trunk Release Motor

	Notes:
	There are currently no notes for this item.




Wiring Photo and Notes: Factory Alarm Arm




Wiring Photo and Notes: Factory Alarm Disarm

	Notes:
	There are currently no notes for this item.




Wiring Photo and Notes: Fuel Pump




Wiring Photo and Notes: Brake Wire

		Notes:
		There are currently no notes for this item.




Wiring Photo and Notes: Parking Brake



Wiring Photo and Notes: Horn Trigger

Notes:
There are currently no notes for this item.



Wiring Photo and Notes: Left Front Speaker (+/-)



Wiring Photo and Notes: Right Front Speaker (+/-)

Notes:

If equipped, the amplifier is in the center of the dash, behind the A/C controls. On vehicles with amplifier, the speaker wires are white - yellow at the amplifier, blue 20 pin plug, pins 2 and 12.



There is currently no photo for this item.

Wiring Photo and Notes: Left Rear Speaker (+/-)

Notes:

If equipped, the amplifier is in the center of the dash, behind the A/C controls. On vehicles with amplifier, the speaker wires are gray - brown at the amplifier, blue 20 pin plug, pins 8 and 18.

Wiring Photo and Notes: Right Rear Speaker (+/-)

Notes:

If equipped, the amplifier is in the center of the dash, behind the A/C controls. On vehicles with amplifier, the speaker wires are blue - orange at the amplifier, blue 20 pin plug, pins 7 and 17.



There is currently no photo for this item.

Wiring Photo and Notes: Subwoofer (+/-)

Notes:

If equipped, the amplifier is in the center of the dash, behind the A/C controls. On vehicles with amplifier, the speaker wires are pink - blue at the amplifier, blue 20 pin plug, pins 5 and 15.

Wiring Photo and Notes: Aux. Audio Input Left (+/-)

	Notes:
	On vehicles with navigation, these wires are in a green 24 pin plug, pins 13 and 1.



Wiring Photo and Notes: Aux. Audio Input Right (+/-)



Wiring Photo and Notes: Satellite Radio 12 Volts

Notes:
If equipped, the XM Receiver is in the passenger kick.



Direct Wil 70

© 2016 Directed. All rights reserved. DirectWire and its vehicle information are for the sole use of authorized Directed personnel and it's participating dealers and distributors. The information contained on these pages may contain confidential and privileged information. Any unauthorized review, use, disclosure or distribution is prohibited.